

# KT45Q

Quick Guide

Android 5.1



## CATALOGUE

KT45Q SPECIFICATION .....	3
<b>1 EXTERNAL STRUCTURE DESCRIPTION.....</b>	<b>5</b>
<b>2 HOME SCREEN.....</b>	<b>6</b>
<b>2.1 Notification Bar Icons .....</b>	<b>7</b>
<b>3 OPERATION INSTRUCTIONS .....</b>	<b>8</b>
<b>3.1 Dialing.....</b>	<b>8</b>
<b>3.3 Shortcut Menu of Notification Bar.....</b>	<b>10</b>
<b>3.4 File Transfer Instructions.....</b>	<b>11</b>
<b>3.5 Main Menu .....</b>	<b>12</b>
<b>3.6 Settings Menu .....</b>	<b>14</b>
<b>3.7 Wireless Network.....</b>	<b>15</b>
<b>3.8 Focus Scanning.....</b>	<b>16</b>
<b>3.9 F1 Key on the keyboard .....</b>	<b>17</b>
<b>4.0 RFID (optional) .....</b>	<b>17</b>
<b>4 CUSTOMER SERVICE AND TECHNICAL SUPPORTER .....</b>	<b>19</b>

## KT45Q SPECIFICATION

BASIC INFORMATION	
CPU	Cortex-A53 1.3GHz-1.5GHz OCTA-core
STORAGE&MEMORY	Flash 8GB RAM 1GB
OS	Android 5.1
CONNECTIVITY	1. Bluetooth: v2.1 +EDR/v3.0+HS/v4.1
	2. WIFI: 802.11 b/g/n/a 2.4G/5G
	3. GPRS /HSPA/EDGE/CDMA2000/TDD/FDD
GPS MODULE	GPS
PC CONNECTOR	USB 2.0 High-Speed
SCREEN	
SCREEN SIZE	4.5" IPS LCD
SCREEN RESOLUTION	480*854
TOUCH SCREEN TYPE	Capacitive Touch screen
BACK LIGHTING	LED
VEDIO FUNCTION	
MAIN CAMERA	800MP
FOCUS MODE	Auto
SENSOR TYPE	CMOS
FLASH	LED
COMMUNICATION MODULE	
COMMUNICATION SPECTRUM	Support two cards
	2G GSM:850/900/1800/1900MHz
	3G TDSCDMA: 1900/2100MHz
	3G WCDMA: 850/900/1900/2100MHz
	4G:TDD-LTE Band: B38/B39/B40/B41
	4G: FDD-LTE Band: B1/B3/B7/B8 CDMA&EVDO BCO
EXPANDABILITY	
BarcodeScanner(support 1D/2D barcode, choose according to demand)	Honeywell: N4313
	Symbol: SE955
	Newland:EM1300
	Motorola: SE4500(1D/2D)
	Newland: EM3095(1D/2D)
	Newland: EM3000(1D/2D)


RFID	1. 13.56MHz(14443A/B,15693,NFC)
	2.UHF 900MHz
	3.LF low frequency(125KHz,134.2KHz)
FingerPrint	optical fingerprint identification
<b>PHYSICAL SPEC</b>	
SIZE	175mm*76mm*28mm
BATTERY	5200mAh, 3.8V or 2600mAh,7.4V
<b>WORK ENVIRONMENT</b>	
WORK TEMPERATURE	-20℃~50℃
HUMIDITY RANGE	5%~95% (no condensation)
DROP SPECIFICATION	Within the scope of operation, all 6 sides can withstand the impact of falling to cement floor from 1.5m in height
SCROLL SPECIFICATION	1000 times 0.5m, 6 rolling contact sides
SEAL GRADE	IP65

# 1 EXTERNAL STRUCTURE DESCRIPTION

























## 2 HOME SCREEN

Home screen shows some important information, such as missed calls and messages. Touch the shortcut menu to make a call, take photos, check or send messages directly and so on.




## 2.1 Notification Bar Icons

	Signal strength		No signal
	GPRS network connected		EDGE network connected
	3G network connected		HSPA network connected
	Roaming		Airplane mode
	Bluetooth on		Receiving location data from GPS
	Speaker activated		Alarm enabled
	Vibration mode		Silence mode
	Call muted		Charging
	Battery full		Battery extremely low
	Call in progress		Missed calls
	Call in progress using a Bluetooth headset		New mail in your Gmail account

## 3 OPERATION INSTRUCTIONS

### 3.1 Dialing

Click **Phone** at **Home Screen** into dial interface. As shown in the figure.



You can use the **Virtual Dial** or press the buttons on device to input number in the input field. Click the number you input to call. Delete error input by delete button. **Call Log** can view all related records. And you can see all saved phone number in **Contacts**.





## 3.2 CAMERA

Click camera icon to take pictures and do a set with the setting button at the bottom left corner.


You can click the direction arrow on the left side to change different scene modes.

You can find your taken pictures in Gallery.



### 3.3 Shortcut Menu of Notification Bar


Slide down the **Notification Bar** two times from the top of the device or slide down it one time and click the circular icon at the top right corner, you will see the following interface and you can set Wi-Fi, bluetooth etc. directly.



There are prompts about connect USB cable and SIM card status. Clicking **Setting Button** could enter system settings directly.

### 3.4 File Transfer Instructions

Make sure there's a SD card in default card slot, check **USB debugging** and the specific process is **Settings→Developer options→USBdebugging(It's checked in default)**. Connect device and PC with USB cable and you will see the first picture after sliding down the **Notification Bar**.




Click **USB connected** to get into the second interface. Click **Turn on USB storage** and android robot will turn into orange after connecting successfully, a removable storage device will display on computer. You can read and write the memory card like operation U disk now. You can install applications by memory card. Firstly copy installation files(\*.apk) of app to SD card, then Turn off USB storage and find the file in SD card, the specific process is **Menu→File Manager**. Click and install it.

### 3.5 Main Menu


Click Menu in Home Screen, you'll see the first picture below.

All about system apps, settings and installed third-party apps are listed here. Click icon to start it. The screen can't display completely If the icons are too many that a screen, please slide around to show more.

Long press any app icon and put it in the pop-up box to be shortcut icon seen as the second picture.




Long press the blank screen, you will see the first picture below. You can click WALLPAPERS to change wallpaper. You can also click WIDGETS seen as the second picture and long press any of it to add it to home screen.



### 3.6 Settings Menu


Click Settings in **Home Screen, Menu** or **Notification Bar** to enter the following interface.

All settings about device are listed here. A total of five classes: WIRELESS & NETWORKS, DEVICE, PERSONAL, ACCOUNT and SYSTEM. Slide up and down to show more. If you want to use WIFI, please open Wi-Fi and connect it. Click Sound and remove the tick of Touch sounds if you want to cancel Touch sounds. The specific process of factory reset in settings is **Backup & reset**→ **Factory data reset**.



### 3.7 Wireless Network

You can surf the net when the device is in wireless network environment. Go into **Settings**, turn Wi-Fi ON below WIRELESS & NETWORKS. Then the network is available. Choose the hotspot you want to connect directly, input password. If it is a network hidden SSID, please click the top right corner menu and choose **Add network** to add it, input SSID and select the security type. You can also click **Advanced Wi-Fi** in the menu to set other advanced options about WI-Fi.




#### VPN settings steps:

Firstly ensure device has connected to network. Then enter Settings→More...→VPN and do set a kind of screen lock. Click Add VPN network, input a name like Vpn and server address. Click Save after inputting the data. Finally, input username and password and connect.

### 3.8 Focus Scanning

The cursor is in an input status, the device can scan barcode and input the result to where cursor is by pressing **SCAN KEY**. Before implement it, you should do a setting. Go into **Settings**→**Accessibility**, and check **Enable Keyreport Scan** just like the pictures below. Then you can use **Focus Scanning**. Check **Enable Keyreport Scan with warning tone** to hear a chime after scanning successfully and you can click **Add Keyvalue** to choose different turning results.



**Note: 1. You should designate the position of cursor before using Focus Scanning, or you won't see the messages about barcode.**

**2. The Add Keyvalue under Enable Keyreport Scan is an option for Focus Scanning. You can choose one to add nothing, a table or an enter after the barcode messages.**



### 3.9 F1 Key on the keyboard

You can input numbers, uppercase letters and lowercase letters with hardware keyboard by pressing F1 key to switch. For example, it inputs numbers at present time, you can press F1 key one time and then you can input lowercase letters.

### 3.10 RFID (optional)

#### 3.10.1 HF

The freq of HF module is 13.56MHz , the device with HF module will add a “-R6” or “-R9” behind the normal name

If the phone has RFID module , open **RC663\_RFID** or **NFC** application. Place a Mifare1 card to the reader range, input a sector number and click **DEMO**. The screen will display the information after reading and writing this sector.

#### 3.10.2 UHF

The freq of UHF module is 900MHz ,the device with UHF module will add a “-UHF” behind the normal name.

If the device has UHF module, choose **As3992demo** in menu, and enter ISO18000-6C,.

First click **SEARCH** key, a dialog will popup. Click **Start** key to begin to search card. When a card is in the valid range, its EPC will be listed in the screen. Click **Stop** key and click the EPC directly to select the card. It will go back to main window, and display the EPC in status bar if it succeeds. Now you can operate the card(read/write/lock).

More information about this demo and developing code please contact the manufacturer to acquire.

### 3.10.3 LF

KT45Q has two types of LF RFID modules. One's freq is 134.2KHz(LF1) and the other's is 125KHz(LF2). The device with LF RFID module is named after a "-LF\*".

If the device has LF module, choose **LRFID** in menu to enter demo, as shown in fig. Click **OFF**, The demo is available if it turns to **ON** and the green bar light on. Place a card near the RFID read area, the card's content will display on the screen.

**When develop application is related to RFID Please contact the phone manufacturer to get more information.**

## 4 SPECIAL CUSTOMIZATION INSTRUCTIONS

This phone has many reserved port to meet the customization. It can connect with RS232, I2C, RS485 and other interface's peripherals or some function modules. Please contact the phone manufacturer to get more information.

## 5 CUSTOMER SERVICE AND TECHNICAL SUPPORTER

Customer service            010 – 82346858 - 801

Technical supporter        Skype:    Android.Speedata

    QQ:    287601031